


# Onan

## Service Manual

### N52M Engine



---

940-0752  
(Spec A-B)  
7-88  
Printed in U.S.A.

# Safety Precautions

It is recommended that you read your engine manual and become thoroughly acquainted with your equipment before you start the engine.

**WARNING** This symbol is used throughout this manual to warn of possible serious personal injury.

**CAUTION** This symbol refers to possible equipment damage.

Fuels, electrical equipment, batteries, exhaust gases and moving parts present potential hazards that could result in serious, personal injury. Take care in following these recommended procedures.

## Safety Codes

- All local, state and federal codes should be consulted and complied with.
- This engine is not designed or intended for use in aircraft. Any such use is at the owner's sole risk.

## General

- Provide appropriate fire extinguishers and install them in convenient locations. Use an extinguisher rated ABC by NFPA.
- Make sure that all fasteners on the engine are secure and accurately torqued. Keep guards in position over fans, driving belts, etc.
- If it is necessary to make adjustments while the engine is running, use extreme caution when close to hot exhausts, moving parts, etc.

## Protect Against Moving Parts

- Do not wear loose clothing in the vicinity of moving parts, such as PTO shafts, flywheels, blowers, couplings, fans, belts, etc.
- Keep your hands away from moving parts.

## Batteries

- Before starting work on the engine, disconnect batteries to prevent inadvertent starting of the engine.
- DO NOT SMOKE while servicing batteries. Lead acid batteries give off a highly explosive hydrogen gas which can be ignited by flame, electrical arcing or by smoking.
- Verify battery polarity before connecting battery cables. Connect negative cable last.

## Fuel System

- DO NOT fill fuel tanks while engine is running.

- DO NOT smoke or use an open flame in the vicinity of the engine or fuel tank. Internal combustion engine fuels are highly flammable.
- Fuel lines must be of steel piping, adequately secured, and free from leaks. Piping at the engine should be approved flexible line. Do not use copper piping for flexible lines as copper will work harden and become brittle enough to break.
- Be sure all fuel supplies have a positive shutoff valve.

## Exhaust System

- Exhaust products of any internal combustion engine are toxic and can cause injury, or death if inhaled. All engine applications, especially those within a confined area, should be equipped with an exhaust system to discharge gases to the outside atmosphere.
- Do not use exhaust gases to heat a compartment.
- Make sure that your exhaust system is free of leaks. Ensure that exhaust manifolds are secure and are not warped by bolts unevenly torqued.

## Exhaust Gas is Deadly!

Exhaust gases contain carbon monoxide, a poisonous gas that might cause unconsciousness and death. It is an odorless and colorless gas formed during combustion of hydrocarbon fuels. Symptoms of carbon monoxide poisoning are:

- Dizziness
- Headache
- Weakness and Sleepiness
- Vomiting
- Muscular Twitching
- Throbbing in Temples

If you experience any of these symptoms, get out into fresh air immediately, shut down the unit and do not use until it has been inspected.

The best protection against carbon monoxide inhalation is proper installation and regular, frequent inspections of the complete exhaust system. If you notice a change in the sound or appearance of exhaust system, shut the unit down immediately and have it inspected and repaired at once by a competent mechanic.

## Cooling System

- Coolants under pressure have a higher boiling point than water. DO NOT open a radiator pressure cap when coolant temperature is above 212°F (100°C) or while engine is running.

## Keep the Unit and Surrounding Area Clean

- Make sure that oily rags are not left on or near the engine.
- Remove all unnecessary grease and oil from the unit. Accumulated grease and oil can cause overheating and subsequent engine damage and present a potential fire hazard.

# Table of Contents

---

TITLE	PAGE
General Information .....	2
Specifications .....	3
Dimensions and Clearances .....	4
Assembly Torques and Special Tools .....	6
Engine Troubleshooting .....	7
Fuel System .....	8
Ignition System .....	14
Battery Charging System .....	16
Oil System .....	19
Starting System .....	21
Engine Disassembly .....	23
Wiring Diagram .....	40

# General Information

## INTRODUCTION

This manual deals with specific mechanical and electrical information needed by engine mechanics for troubleshooting, servicing, repairing, or overhauling the engine.

Use the table of contents for a quick reference to the separate engine system sections.

Use the separate Parts Catalog (940-0252), available at the dealer level, for parts identification and for establishing their proper location on assemblies.

The troubleshooting guide is provided as a quick reference for locating and correcting engine trouble.

The illustrations and procedures presented in each section apply to the engine on the cover. The flywheel-blower end of the engine is the front end so right and left sides are determined by viewing the engine from the front.

The disassembly section contains major overhaul procedures for step by step removal, disassembly, inspection, repair and assembly of the engine components.

If a major repair or an overhaul are necessary, a competent mechanic should either do the job or supervise and check the work of the mechanic assigned to do the job to ensure that all dimensions, clearances and torque values are within the specified tolerances.

The wiring diagram on the last page of the manual shows how the electrical components are interconnected.


A parts catalog (available at the dealer level) contains detailed exploded views of each assembly and the individual piece part numbers and their proper names for ordering replacement parts.

Use only Genuine Onan replacement parts to ensure quality and the best possible repair and overhaul results. When ordering parts, always use the complete Model and Spec number as well as the Serial number shown on the nameplate.

## ENGINE MODEL REFERENCE

Identify your model by referring to the MODEL and SPEC (specification) NO. as shown on the unit nameplate. Always use this number and the engine serial number when making reference to your engine.

How to interpret MODEL and SPEC NO.



1. Factory code for general identification of basic engine series.
2. Cubic inch displacement.
3. Engine duty cycle (M=medium duty).
4. Fuel required (G=gasoline).
5. Cooling system description (A=air-cooling-pressure).
6. BHP rating.
7. Factory code for designated optional equipment, if any.
8. Specification (spec letter) which advances with factory production modifications.

### WARNING

**INCORRECT SERVICE OR REPLACEMENT OF PARTS MIGHT RESULT IN SEVERE PERSONAL INJURY AND/OR EQUIPMENT DAMAGE. SERVICE PERSONNEL MUST BE QUALIFIED TO PERFORM ELECTRICAL AND/OR MECHANICAL SERVICE.**

# Specifications

This manual contains S1 metric equivalents that follow immediately in parentheses after the U.S. customary units of measure.

SPECIFICATION	UNIT OF MEASURE	SERIES
		N52M
Number of Cylinders		2
Bore	in (mm)	3.56 (90.48)
Stroke	in (mm)	2.64 (67)
Displacement	cu in (cm <sup>3</sup> )	52.2 (858)
Compression Ratio		6.5 to 1
Rated Speed (Maximum)	RPM	3600
Power at Rated Speed	BHP (kW)	19.9 (15.2)
Oil Filter		Full Flow
Oil Capacity Without Filter	Qt (litre)	3.5 (3.3)
Oil Capacity With Filter Change	Qt (litre)	4.0 (3.8)
Crankshaft Rotation (viewed from flywheel)		Clockwise
Governor		Variable Speed Mechanical
Valve Clearance (Cold)		
Intake	in (mm)	0.005 (0.127)
Exhaust (Gasoline Fuel)	in (mm)	0.013 (0.330)
Exhaust (Lpg and Natural Gas)	in (mm)	0.013 (0.330)
Spark Plug Gap	in (mm)	0.025 (0.64)
Breaker Point Gap - Static (Full Separation and Engine Cold)	in (mm)	0.020 (0.51)
Ignition Timing	BTC	25°

# Dimensions and Clearances

All clearances given at room temperature of 70°F (21°C). All dimensions in inches (approximate millimetre dimensions in parentheses) unless otherwise specified.

DESCRIPTION	MINIMUM		MAXIMUM	
	Inches	(mm)	Inches	(mm)
<b>CYLINDER BLOCK</b>				
Cylinder Bore Honed Diameter .....	3.5625	(90.49)	3.5635	(90.51)
Maximum Allowable				
Taper .....			0.003	(0.08)
Out-of-Round .....			0.003	(0.08)
Main Bearing Inside Diameter (Without bearing) .....	2.187	(55.55)	2.188	(55.58)
Main Bearing Inside Diameter (Installed) .....	2.0015	(50.84)	2.0040	(50.90)
Camshaft Bearing Bore (Bearing installed) .....	1.3760	(34.95)	1.3770	(34.98)
<b>CRANKSHAFT</b>				
Main Bearing Journal Diameter .....	1.9992	(50.78)	2.0000	(50.80)
Main Bearing Clearance .....	0.0015	(0.04)	0.0043	(0.11)
Connecting Rod Journal Diameter .....	1.6252	(41.28)	1.6260	(41.30)
Crankshaft End Play .....	0.005	(0.13)	0.009	(0.23)
<b>CONNECTING ROD</b>				
Large Bore Diameter				
(Without bearing installed and rod bolts properly torqued) Spec A .....	1.7505	(44.46)	1.7510	(44.48)
(Rod bolts properly torqued) Begin Spec B .....	1.6280	(41.35)	1.6285	(41.36)
Connecting Rod Side Clearance .....	0.0020	(0.051)	0.0160	(0.406)
Piston Pin Bushing Bore (Without bearing) .....	0.8115	(20.61)	0.8125	(20.64)
Piston Pin Bushing Bore with Bearing, (Finished bore) .....	0.7504	(19.06)	0.7508	(19.07)
Bearing to Crankshaft Clearance				
Nodular Iron Rod .....	0.0005	(0.013)	0.0028	(0.071)
Aluminum Rod .....	0.0020	(0.051)	0.0033	(0.084)
<b>CAMSHAFT</b>				
Bearing Journal Diameter .....	1.3740	(34.90)	1.3745	(34.91)
Bearing Clearance .....	0.0015	(0.038)	0.0030	(0.076)
End Play .....	0.0030	(0.076)	0.0120	(0.305)
Camshaft Lift .....		0.300	(7.62)	
<b>PISTON</b>				
Clearance in Cylinder				
Measure 90° to pin 0.10 inch below oil ring				
Strut Type Spec A .....	0.0015	(0.038)	0.0035	(0.089)
Without Strut Begin Spec B .....	0.0070	(0.178)	0.0090	(0.229)
Piston Pin Bore .....	0.7502	(19.055)	0.7506	(19.065)
Ring Groove Width				
Top 1 Compression Ring Spec A .....	0.0955	(2.426)	0.0965	(2.451)
Top 1 Compression Ring Begin Spec B .....	0.080	(2.032)	0.081	(2.057)
No. 2 Compression Ring Spec A .....	0.0955	(2.426)	0.0965	(2.451)
No. 2 Compression Ring Begin Spec B .....	0.080	(2.032)	0.081	(2.057)
No. 3 Oil Control Ring .....	0.188	(4.775)	0.189	(4.801)

DESCRIPTION	MINIMUM		MAXIMUM	
	Inches	(mm)	Inches	(mm)
<b>PISTON PIN</b>				
Clearance in Piston .....	0.0001	(0.003)	0.0005	(0.013)
Clearance in Connecting Rod				
Nodular Iron Rod .....	0.00005	(0.001)	0.00055	(0.014)
Aluminum Rod .....	0.0002	(0.005)	0.0008	(0.020)
Diameter .....	0.7500	(19.05)	0.7502	(19.06)
<b>PISTON RINGS</b>				
Clearance				
Top Groove .....	0.002	(0.051)	0.008	(0.203)
Ring End Gap in Cylinder .....	0.010	(0.254)	0.020	(0.508)
<b>INTAKE VALVE</b>				
Stem Diameter .....	0.3425	(8.70)	0.3430	(8.71)
Clearance (Stem to Guide) .....	0.0010	(0.025)	0.0025	(0.064)
Valve Face Angle .....			44°	
<b>INTAKE VALVE SEAT</b>				
Seat Cylinder Head Bore Diameter .....	1.5645	(39.74)	1.5655	(39.76)
Seat Outside Diameter .....	1.5690	(39.85)	1.5700	(39.88)
Valve Seat Width .....	0.031	(0.787)	0.047	(1.194)
Valve Seat Angle .....			45°	
<b>EXHAUST VALVE</b>				
Stem Diameter .....	0.3410	(8.661)	0.3415	(8.674)
Clearance (Stem to Guide) .....	0.0025	(0.064)	0.064	(0.163)
Valve Face Angle .....			44°	
<b>EXHAUST VALVE SEAT</b>				
Seat Cylinder Head Bore Diameter .....	1.2510	(31.78)	1.2520	(31.80)
Seat Outside Diameter .....	1.2550	(31.88)	1.2560	(31.90)
Valve Seat Width .....	0.031	(0.787)	0.047	(1.194)
Valve Seat Angle .....			45°	
<b>VALVE GUIDE</b>				
Inside Diameter .....	0.344	(8.74)	0.346	(8.79)
<b>TAPPET</b>				
Body Diameter .....	0.7475	(18.99)	0.7480	(19.00)
Bore Diameter .....	0.7505	(19.06)	0.7515	(19.09)
Clearance in Bore .....	0.0015	(0.038)	0.003	(0.076)
<b>VALVE SPRINGS INTAKE AND EXHAUST</b>				
Valve Spring Free Length (Approx.) .....			1.662	(42.21)
Valve Spring Length				
Valve Open .....			1.125	(28.58)
Valve Closed .....			1.375	(34.93)
Spring Load @ 1.375 inch (Valve Closed) .....	38 lb.	(17 kg)	42 lb.	(19 kg)
Spring Load @ 1.125 inch (Valve Open) .....	71 lb	(32 kg)	79 lb	(36 kg)
<b>GEAR BACKLASH</b>				
Timing Gear .....	0.002	(0.051)	0.003	(0.076)
Oil Pump Gear .....	0.002	(0.051)	0.005	(0.127)

# Assembly Torques

The torque values given in Table 1 have been determined for the specific applications. Standard torque values must not be used where those listed in Table 1 apply. The engine assembly torques given here will assure proper tightness without danger of stripping threads. All threads must be clean and lubricated with new engine oil before torquing.

Check all studs, nuts, and capscrews, and tighten as required to keep them from working loose. Refer to the *PARTS MANUAL* for the location of washers and capscrews.

TABLE 1.

DESCRIPTION	TORQUE SPECIFICATION		DESCRIPTION	TORQUE SPECIFICATION	
	Ft.-Lb.	Nm		Ft.-Lb.	Nm
Cylinder Head Nuts (Cold)			Rear Bearing Plate .....	25-28	(34-38)
Asbestos Gasket without			Connecting Rod Bolt		
Compression Washers .....	18-20	(24-27)	Iron Rod .....	27-29	(37-39)
Asbestos Gasket with			Aluminum Rod .....	14-16	(19-22)
Compression Washers .....	13-15	(18-20)	Flywheel Capscrew .....	50-55	(68-75)
Graphoil Gasket without			Starter Mounting Bracket to		
Compression Washers .....	14-16	(19-22)	Oil Base Screws .....	25-35	(34-47)
Graphoil Gasket with			Gear Case Cover .....	8-10	(11-14)
Compression Washers .....	11-13	(15-18)	Oil Pump .....	7-9	(10-12)
			Other 3/8 Cylinder Block		
			Nuts .....	18-23	(24-31)
			Intake Manifold .....	20-23	(27-31)
			Exhaust Manifold .....	20-23	(27-31)

## Special Tools

The following special tools are available from Onan. For further information see *TOOL CATALOG 900-0019*.

- Valve Seat Driver*
- Valve Guide Driver*
- Oil Seal Guide and Driver*
- Combination Bearing Remover (Main and Cam)*
- Combination Bearing Driver (Main and Cam)*
- Flywheel Puller*

# Engine Troubleshooting

another free manual from www.searstractormanuals.com

TROUBLE											CAUSE											
Backfire at Carburetor	Backfire at Valve	Black Exhaust	Blue Exhaust	Burned Valves	Connecting Rod Wear	Cranks Slowly	Cylinder Wear	Failure to Start	Failure to Stop	Governor Hunting	High Oil Pressure	Loss of Oil Pressure	Loss of Coolant (Water Cooled)	Mechanical Knock	Overheating (Air Cooled)	Overheating (Water Cooled)	Piston Wear	Ring Compression	Ring Wear	Sticking Valves		
<b>STARTING SYSTEM</b>																						
																					Loose or Corroded Battery Connection	
																						Low or Discharged Battery
																						Faulty Starter
																						Faulty Start Solenoid
<b>IGNITION SYSTEM</b>																						
																						Ignition Timing Wrong
																						Wrong Spark Plug Gap
																						Worn Points or Improper Gap Setting
																						Bad Ignition Coil or Condenser
																						Faulty Spark Plug Wires
<b>FUEL SYSTEM</b>																						
																						Out of Fuel - Check
																						Lean Fuel Mixture - Retarded
																						Rich Fuel Mixture or Choke Stuck
																						Engine Floodes
																						Poor Quality Fuel
																						Dirty Carburetor
																						Dirty Air Cleaner
																						Dirty Fuel Filter
																						Defective Fuel Pump
<b>INTERNAL ENGINE</b>																						
																						Wrong Valve Clearance
																						Broken Valve Springs
																						Valve or Valve Seat Leaking
																						Piston Rings Worn or Broken
																						Wrong Bearing Clearance
<b>COOLING SYSTEM - AIR COOLED</b>																						
																						Poor Air Circulation
																						Dirty or Oily Cooling Fans
																						Broken Head Gasket
<b>LUBRICATION SYSTEM</b>																						
																						Defective Oil Gauge
																						Relief Valve Stuck
																						Faulty Oil Pump
																						Dirty Oil or Filter
																						Oil Too Light or Diluted
																						Oil Level Low
																						Oil Too Heavy
																						Dirty Crankcase Breather Valve
<b>THROTTLE AND GOVERNOR</b>																						
																						Linkage Out of Adjustment
																						Linkage Worn or Disconnected
																						Governor Spring Sensitivity Too Great
																						Linkage Binding

# Fuel System

## CARBURETOR ADJUSTMENTS

The carburetor mixture screws and the float level were set for maximum efficiency at the factory and will seldom require readjustment. If adjustment seems necessary, first be sure the ignition system is working properly and is not the source of the problem.

The engine may be equipped with a sidedraft carburetor or a downdraft LUA carburetor. In most cases carburetor adjustment procedures are the same for either type. Differences will be specified within the adjustment instructions. LUA carburetor design is specified by number (LUA 5, LUA 9, etc.). This number is stamped into the body of the carburetor below the main fuel adjustment. See Figure 11 for location of the stamping. Refer to Table 1 for initial mixture screw and float level specifications.

TABLE 1. CARBURETOR ADJUSTMENT SPECIFICATIONS

CARBURETOR	MIXTURE SETTINGS		FLOAT* LEVEL
	IDLE	MAIN	
LUA 2	1-1/2 to 1-3/4	1 to 1-1/4	.02 ± .02" (.5 ± .5 mm)
LUA 9	1-1/8 to 1-3/8	1-1/8 to 1-3/8	.02 ± .02" (.5 ± .5 mm)

\*When checking float drop and float level, measure to float body, not seam.



### Mixture Screw Adjustment

1. Turn both mixture screws in until lightly seated, then back them out the number of turns specified in Table 1.

**WARNING** Loosen packing nut before turning main fuel adjustment and tighten to a snug fit after adjustment has been made. Hold the adjustment while tightening packing nut. Failure to tighten the packing nut may result in leaking fuel, creating a serious fire hazard.

**CAUTION** Forcing the mixture adjustment screws tight will damage the needle and seat. Turn in only until light tension can be felt.

2. Start the engine and allow it to warm up thoroughly (at least 10 minutes).
3. Set low speed adjustment. Move engine speed control to SLOW position. The engine should run at about 1200 rpm.



LOW SPEED ADJUSTMENT

FIGURE 1. CARBURETOR ADJUSTMENTS

4. Turn the idle needle out (counterclockwise) until engine begins to slow down or run unevenly. Remember this position; see Figure 1.
5. Turn needle in (clockwise) past the position where the engine runs smoothly until it begins to slow down or run unevenly.
6. Back the needle out to a position approximately halfway between the two positions. This should provide a smooth running idle.

### Throttle Stop Screw

The throttle stop screw is located on the base of the carburetor (opposite side from main power adjustment needle) near the crankcase breather valve. It must be adjusted for desired idle speed at no load with the throttle closed as far as possible (throttle shaft lever touching adjustment screw). See Figure 2.




FIGURE 2. THROTTLE STOP SCREW SETTING

### Carburetor Main (Load) Adjustment


If engine runs unevenly at half or full load due to faulty carburetion, the main adjusting needle needs readjustment (Figure 1).

1. Start engine and allow it to warm up.
2. Push in on the governor mechanism to slow the unit down to about 400 to 500 rpm.
3. Set idle adjustment so engine runs smoothly.
4. Release governor mechanism to allow engine to accelerate. If engine accelerates evenly and without hesitation, main adjustment is correct. If not, turn needle outward about one half turn and again slow the engine down and release the mechanism. Continue until the engine accelerates evenly and without a hesitation after releasing the governor.
5. If engine tends to hunt (alternate increase and decrease of speed), open the main adjusting needle a little more. Do not open more than one half turn beyond the maximum power point.


### Float Adjustment

An exceedingly high float setting will usually result in an engine that is hard to start when warm. If the setting is too low, the engine may not receive enough fuel under sudden acceleration or load change. Adjust setting as follows:


1. Disconnect throttle control, choke leads, breather hose, air cleaner inlet hose, and fuel line from carburetor.
2. Remove the four bolts that hold the intake manifold assembly in place and remove the complete carburetor and intake manifold assembly as one unit. Then remove carburetor from intake manifold for easier handling when checking float level.
3. Separate the upper body of the carburetor from the fuel bowl section.



FLOAT LEVEL ADJUSTMENT



NO FUEL



FLOAT DROP ADJUSTMENTS

FS-1524

FIGURE 3. FLOAT LEVEL ADJUSTMENT

4. Turn the upper body of the carburetor so that the float assembly is resting on the inlet needle valve.
5. Measure the distance between the carburetor body and the free end of the float (Figure 3). Refer to Table 1 for the correct float level.

LUA series carburetors have the float assembly mounted in the fuel bowl section of the carburetor. Float measurement is made by turning the fuel bowl section and measuring the distance from the float to a straight edge laid across the body of the fuel bowl (Figure 3).

6. If the setting is incorrect, remove the float assembly to adjust. Bend the assembly slightly at the location specified in Figure 3.

**CAUTION** Attempting adjustments with the float assembly installed may result in deformation of the inlet needle and seat.

## CARBURETOR OVERHAUL

Carburetion problems that are not corrected by mixture or float adjustments are usually a result of gummed-up fuel passages or worn internal parts. The most effective solution is a complete carburetor overhaul.

In general, overhauling a carburetor consists of complete disassembly, a thorough cleaning, and replacement of worn parts. Carburetor repair kits are available that supply new gaskets and replacements for those parts most subject to wear.

General instructions for overhauling a carburetor are given below. Carefully note the position of all parts while removing to assure correct placement when reassembling. Read through all the instructions before beginning for a better understanding of the procedures involved. Carburetor components are shown in Figure 4.

**WARNING** Ignition of fuel might cause serious personal injury or death by fire or explosion. Do not permit any flame, cigarette, or other igniter near the fuel system.

### Removal and Disassembly

1. Disconnect all lines, linkages, wires, and attaching nuts or bolts; then remove the carburetor and manifold from the engine.
2. Remove air cleaner adapter, if so equipped, and automatic choking assembly.
3. Remove throttle and choke plate retaining screws, then plates. Pull out throttle and choke shafts, being careful not to damage the teflon coating applied to some throttle shafts.
4. Remove main and idle mixture screw assemblies.
5. Remove attaching screws and separate upper and lower carburetor sections.
6. Carefully note position of float assembly parts, then slide out retaining pin and remove the float assembly, any springs or clips, and the needle valve.
7. Unscrew and remove needle valve seat.

### Cleaning and Repair

1. Soak all metal components not replaced by repair kit in carburetor cleaner. Do not soak non-metal floats or other non-metal parts. Follow the cleaner manufacturer's recommendations.
2. Clean all carbon from the carburetor bore, especially where the throttle and choke plates seat. Be careful not to plug the idle or main fuel ports.
3. Blow out all passages with compressed air. Avoid using wire or other objects for cleaning that may increase the size of critical passages.




FIGURE 4. DOWNDRAFT LVA CARBURETOR ASSEMBLY

4. Check the condition of any needle valve not included in repair kit and replace if damaged. Replace float if loaded with fuel or damaged.
5. Check the choke and throttle shafts for excessive play in their bore, and replace if necessary.
6. Replace old components with new parts included in repair kit.

### Reassembly and Installation

1. Install needle valve and seat, and float assembly. Make sure that all clips and springs are properly placed and that the float moves freely without binding. Check float level and adjust as necessary (see *Float Level Adjustment*).
2. Rejoin upper and lower carburetor sections on downdraft carburetors.
3. Slide in throttle shaft and install throttle plate, using new screws if furnished in repair kit. Before tightening the screws, the plate must be centered in the bore. To do so, back off the throttle stop screw as necessary and completely close the throttle lever. Seat the plate by tapping with small screwdriver, then tighten screws. Install the choke shaft and plate in the same manner.

4. Install main and idle mixture screw assemblies. Turn in screws until lightly seated and then out the number of turns specified in Table 1.

**CAUTION** Forcing the mixture adjustment screws tight will damage the needle and seat. Turn in only until light tension is felt.

5. Reinstall carburetor on engine and connect fuel lines, linkages, and wires.
6. Reset mixture screws according to directions given earlier in this section. Install air cleaner adapter, where used, and air cleaner.

### PULSATING-DIAPHRAGM FUEL PUMP

Pulsating-diaphragm fuel pumps use a combination of crankcase and spring pressure to work a diaphragm and pump the fuel. See Figure 5.

On the downstroke of the engine piston, when crankcase pressure is greatest, the pump diaphragm is forced back against the diaphragm spring compressing it and drawing fuel into the pump intake chamber. The fuel then passes through the intake reed valve into the output chamber side of the pump. On the compression stroke, when crankcase pressure is the lowest, the diaphragm spring forces the diaphragm out pushing fuel through the pump output reed valve into the output chamber and into the fuel line.

### Pulse Pump Repair

1. Remove the vacuum and fuel lines. Inspect the lines for wear, cracking, and brittleness. Replace as necessary.
2. To insure correct alignment when reassembling, scribe a line across the outer pump parts on each end of the pump (Figure 5).
3. Holding the pump carefully, remove the assembly screws.
4. Carefully pull apart the pump sections and check for worn or damaged parts. Replace with new parts where necessary or install pump repair kit.
5. Check and unclog (if necessary) the small diaphragm air bleed hole located behind the pump diaphragm in the pump base (Figure 5).

**CAUTION** A clogged diaphragm air bleed hole can cause diaphragm wear and seal damage while inhibiting pump operation.

6. Replace gaskets and reassemble pump. Reinstall assembly screws, checking the scribe marks for proper alignment. Reinstall fuel and vacuum lines and clamps.

**WARNING** Fuel leakage is a fire and explosion hazard that might cause severe personal injury or death. Use care when reassembling fuel pump. All parts must align perfectly or pump will leak fuel.




FIGURE 5. PULSE PUMP - EXPLODED VIEW

## GOVERNOR ADJUSTMENT

The factory sets the governor for a nominal engine speed of 2400 rpm at no-load operation (unless another speed is specified when the engine is ordered). Proper governor adjustment is one of the most important factors in maintaining the power and speed desired from the engine.

Make sure the carburetor is properly adjusted before checking or changing governor settings.

Before making the governor adjustments, run the engine about 15 minutes to reach normal operating temperature. A tachometer for checking engine speed is required for accurate governor adjustment.

It is difficult to determine if, after long usage, the governor spring has become fatigued. If regulation is still erratic after properly making all adjustments install a new spring, Figure 6.




FIGURE 6. VARIABLE SPEED GOVERNOR REMOTE CONTROL

Check the governor arm, linkage, throttle shaft and lever for binding or excessive wear at connecting points. A binding condition at any point will cause the governor to act slowly and regulation will be poor. Excessive looseness will cause a hunting condition and regulation will be erratic. Work the arm back and forth several times by hand while the engine is idling. If either of these conditions exist, determine the cause and adjust or replace parts as needed.

### Linkage Adjustment

The engine starts at wide open throttle. You can adjust the length of the linkage connecting the governor arm to the throttle arm by using one of three holes in the arm. Adjust the length so that with the engine stopped and tension on the governor spring, the stop on the carburetor throttle lever is 1/32 inch (0.8 mm) from the carburetor stop boss. This setting allows immediate control by the governor after starting and synchronizes travel of the governor arm and the throttle shaft.

### Speed Adjustment

The speed at which the engine operates is determined by the tension applied to the governor spring. Increasing spring tension increases engine speed, decreasing spring tension decreases engine speed. The no-load speed of the engine should be slightly higher than the requirements of the connected load. For example: If the connected load has to turn at 3510 rpm, set the no-load speed of the engine at about 3600 rpm. Check speed with a tachometer. If a speed adjustment is needed, turn the speed adjusting nut in to increase the speed or out to decrease the speed.

### Sensitivity Adjustment

Engine speed from no load to full load should not drop less than 100 rpm. Check the engine speed with no load connected and again after connecting full load. Do not exceed 4000 rpm at no load.

The sensitivity of the governor depends upon the position of the arm end of the governor spring. A series of holes in the governor arm provides for adjustment. To increase sensitivity, move the spring toward the governor shaft. To decrease sensitivity, move the spring toward the linkage end of the governor arm.

If the setting is too sensitive, a hunting condition (alternate increase and decrease in engine speed) will

result. If the setting is not sensitive enough, the speed variation between no-load and full-load conditions will be too great. Therefore, the correct sensitivity will result in the most stable speed regulation without causing a surge condition.

Always recheck the speed adjustment after a sensitivity adjustment. Increasing sensitivity will cause a slight decrease in speed and will require a slight increase in the governor spring tension.

### Variable Speed Governor Adjustments

These engines are adapted for a wide range of speed settings. The design of the variable speed governors gives an automatic increase in sensitivity when the speed is increased and the result is good stability at all speeds.

Approximately 3000 rpm is the recommended maximum full-load speed for continuous operation. The speed must agree with the load requirements.

To adjust the remote control variable speed governor (Figure 6), proceed as follows:

1. The governor control spring is factory set in the center hole of the governor control shaft bracket. To increase the sensitivity, move the spring loop into the hole nearest the control shaft. To decrease the sensitivity, move the spring outward.
2. After sensitivity has been set, adjust the low speed stop adjustment screw on the control wire bracket until a fast idle is obtained, (about 1200 rpm).


## AIR CLEANER

**CAUTION** *If air cleaner becomes too dirty, engine will not receive sufficient air to run properly. Symptoms: Loss of power, flooding, hard starting, and overheating.*

Engine is equipped with a paper element. If the engine is equipped with polyurethane pre-cleaner it must be removed, cleaned, and oiled every 25 hours of operation, or more often under extremely dusty conditions.

1. To clean pre-cleaner wash in water and detergent, referring to Figure 6a. Remove excess water by squeezing like a sponge and allow to dry thoroughly.
2. Distribute two tablespoons of SAE 30 engine oil evenly around the pre-cleaner. Knead into pre-cleaner and wring out excess oil.
3. Depending on conditions in which the engine is operating, the inner paper element should be replaced whenever it becomes excessively dirty or oily.

**CAUTION** *Never run engine with air cleaner removed. Dirt will enter engine and wear out rings causing excessive blow-by.*



- 1 WASH
- 2 SQUEEZE DRY
- 3 COAT WITH OIL
- 3 INSTALL OVER PAPER ELEMENT



M-1318

FIGURE 6a. AIR CLEANER ASSEMBLY

# Ignition System

## IGNITION TIMING

The timing on the engine is preset at the factory. A non-movable breaker point box is used, however a slight timing change could be made by adjusting points.

The engine is equipped with an automotive type battery ignition system. Both spark plugs fire simultaneously, thus the need for a distributor is eliminated. Spark advance is set at 25° BTC (before top center), and should be maintained for best engine performance. Always check timing after replacing ignition points or if noticing poor engine performance. Proceed as follows:

### Timing Procedure — Engine Running and Hot

1. To accurately check ignition timing, use a timing light when engine is running. Connect timing light according to its manufacturer's instructions. Either spark plug can be used as they fire simultaneously.
2. Remove the air intake hose that connects to blower housing to provide an access to view timing marks.

3. Start the engine and check the timing. The TC mark on the flywheel should line up with the 25° mark on the gear cover (see Figure 7).

If timing marks do not line up, readjust point gap. To advance timing, slightly open gap on breaker points. To retard timing, slightly close gap on breaker points. Recheck timing and breaker point gap after making this adjustment.

4. Replace hose, breaker box cover and any other hardware removed from engine

### TOP ADJUST BREAKER POINTS — TIMING (Cold Setting)

To maintain maximum engine efficiency, change the breaker points every 200 hours of operation. Proceed as follows:

1. Remove the air intake hose that connects to blower housing. This provides an access to view timing mark. See Figure 7.
2. Remove spark plugs and rotate flywheel TC mark clockwise to 25° BTC (points open).
3. Remove breaker box cover and unplug coil wire at coil (+) terminal.
4. Remove condenser (screw A) and detach condenser lead and coil lead (screw B), Figure 7.





FIGURE 7. BREAKER POINTS-TIMING

5. Remove two allen screws (C) and lift breaker assembly from engine.
6. Replace condenser and point assembly with new parts and reinstall using above procedure in reverse order of removal.
7. Connect an ohmmeter or a continuity test lamp set across the ignition breaker points. Touch one test prod to the breaker box terminal to which the coil lead is connected and touch the other test prod to a good ground on the engine.
8. Turn crankshaft against rotation (counterclockwise) until the points close. Then slowly turn the crankshaft with rotation (clockwise).
9. The lamp should go out just as the points break which is the time at which ignition occurs (25° BTC).
10. If timing is early (large point gap) or late (small point gap), adjust point gap using Allen screw (D) so that lamp goes out at 25° BTC with crankshaft rotation clockwise.

If a continuity lamp or an ohmmeter is not available, use a clean flat feeler gauge as follows: Rotate crankshaft clockwise (facing flywheel) by hand until TC mark on flywheel aligns with 25° BTC mark on gear cover. Then rotate flywheel another 1/4 turn clockwise (90°) to ensure points open fully. Using Allen screw (D), set point gap at .020 inch (0.51 mm).

11. Replace breaker box cover, coil wire and spark plug cables and air intake hose.

### IGNITION COIL

To test primary and secondary windings within the ignition coil, proceed as follows:

1. Use a Simpson 270 VOM or equivalent.
2. Place a black lead on ground (-) terminal of coil and red lead to positive (+) terminal. Primary resistance should read 4.30 (± 10%) ohms @ 70 F (21 C). See Figure 8.
3. Change resistance setting on ohmmeter. Place ohmmeter leads inside of spark plug cable holes. Secondary resistance should read 14,000 (± 10%) ohms @ 70 F (21 C).
4. If any of the above conditions are not met, replace coil. Refer to an Onan PARTS CATALOG for correct part number.

**CAUTION** *This engine uses a 12-volt, negative ground system. Alternator must be connected to battery at all times when engine is running. Do not reverse battery cables.*




FIGURE 8. COIL TEST

### SPARK PLUGS

Remove both spark plugs (see Figure 8a) and install new ones every 100 hours.

Check to be sure spark plug gap is set at 0.025 inch (0.64 mm).




FIGURE 8a. SPARK PLUG GAP

# Battery Charging System

## BATTERY CHARGING, FLYWHEEL ALTERNATORS

The flywheel alternator is a permanent magnet alternator and uses a solid-state voltage regulator-rectifier for controlling output. The alternator is a 15-ampere Phelon system.

Weak ignition spark or a discharged battery indicate trouble in the charging system. But before testing the engine's charging system, always check the battery for serviceability.

Keep these points in mind when testing or servicing the flywheel alternator:

1. Be sure output control plug (connector) is inserted properly. Plug must bottom in receptacle—eliminates any resistance due to a poor connection. Keep clean and tight.
2. Make sure alternator stator leads are not shorted together.
3. Be sure regulator-rectifier output control has a good ground connection. Mating surface for mounting must be clean and fasteners tightened properly.
4. Never reverse the battery leads.

Charging system tests require a full charged battery.

### 15-AMPERE PHELON SYSTEM

The 15-ampere flywheel alternator systems (Figure 9) have a one piece regulator-rectifier assembly. Various alternator problems are listed in Table 1.




FIGURE 9. 15-AMPERE PHELON SYSTEM

TABLE 1. TESTING PHELON 15-AMPERE SYSTEM

BASIC TEST	PROCEDURE	TEST VALUES
1. Battery	Battery Voltage — unit not running	12 VDC
2. Regulator	Battery Voltage after unit is running 3 to 5 minutes	13.6 to 14.7 VDC
3. Alternator Stator and Wiring	Ohmmeter reading from stator output — unit not running. Check at plug.	0.11 to 0.19 Ohms
4. Alternator and Wiring	Measure AC open circuit stator voltage with unit running. Measure between two stator leads with plug disconnected and unit running at approximately 3600 rpm.	28 VAC minimum 65 VAC maximum

With the engine running between 1800 to 2600 rpm, observe the panel ammeter (if not already equipped, connect a test ammeter). If no charging is evident, proceed with the *No Charge Test*. If ammeter shows a constant higher charge rate, follow the *High Charge Rate Test* procedure.

### No Charge Test

1. Check the B+ to ground voltage using a DC voltmeter. See Figure 10 for wiring diagram.
2. If voltmeter reads 13.8 volts or higher, add a load to system (e.g. headlights) to reduce battery voltage to below 13.6 volts.
3. Observe ammeter. If charge rate increases, consider the system as satisfactory. If charge rate does not increase, proceed with testing.
4. Disconnect plug from regulator-rectifier and test the AC voltage at the plug with engine running near 3600 rpm. If AC voltage reads less than 28 volts, replace the stator. If AC voltage is greater than specified in TABLE 1, replace the regulator-rectifier assembly.




FIGURE 10. 15-AMPERE PHELON SYSTEM DIAGRAM

### High Charging Rate Test

Perform this test as follows:

1. Check B+ to ground voltage with a DC voltmeter.
2. If voltmeter reads over 14.7 volts, replace regulator-rectifier assembly.
3. If reading is under 14.7 volts, the system is probably okay. Recheck the battery and connections. If the battery does have a low charge, but accepts recharging, system is okay.

## BATTERY INSPECTION

Check battery cells with a hydrometer. The specific gravity reading should be approximately 1.260 at 77 F (25 C), Figure 11.

If one or more cells are low on water, add distilled water and recharge. Keep the battery case clean and dry. An accumulation of moisture will lead to a more rapid discharge and battery failure.




FIGURE 11. SPECIFIC GRAVITY TEST

**WARNING** Do not smoke while servicing batteries. Explosive gases are emitted from batteries while charging. Ignition of these gases can cause severe personal injury.

Keep the battery terminals clean and tight. Push the cable terminal down flush with or slightly below the top of the battery post (Figure 12). After making connections, coat the terminals with a light application of petroleum jelly or grease to retard corrosion.




FIGURE 12. BATTERY CABLE CONNECTION

## BATTERY JUMP STARTING

Occasionally, it may be necessary to jump start (charge) a weak battery using a charged booster battery to start your engine. If jump starting is necessary, the following procedure is recommended in order to prevent battery damage and personal injuries.

**CAUTION** *Do not engage starter for periods longer than 30 seconds without allowing 5 minutes for starter to cool. Starter failure may result if these guidelines are not followed.*

1. Disconnect engine load.
2. Turn ignition switch to ON so engine will start.
3. Use only a battery of the same voltage (12V) as is used with your engine.
4. Attach one end of the positive booster cable (red) to the positive (+) terminal of the booster battery. Attach the other end of the positive cable to the positive (+) terminal of your engine battery.
5. Attach one end of the negative (-) booster cable (black) to negative (-) terminal of booster battery. Attach other end of negative cable to a solid chassis ground on your engine.

**WARNING** *Arcing may cause severe personal injury. Do not allow the positive and negative cable ends to touch each other because it will short the battery causing arcing.*

6. Jump starting in any other manner may result in damage to the battery or the electrical system.

**WARNING** *A frozen battery may explode and might cause severe personal injury. Never jump start a frozen battery. To do so may cause the battery to explode. Never expose the battery to an open flame or an electrical spark because a battery creates highly explosive hydrogen gas.*

## FLYWHEEL ALTERNATOR

### Precautions

1. Do not connect battery cables in the wrong polarity.
2. Do not short together alternator stator leads.
3. Do not run without a battery. Damage will occur to regulator and battery ignition coil.

### Preservice Checks

1. Check for a good ground between equipment and regulator-rectifier case.
2. Be sure output control plug (connector) is properly inserted into stator receptacle. This means the plug must push in and solidly bottom in the receptacle to eliminate any resistance due to a poor connection. Keep it clean and tight.
3. Check battery and its connection to be sure it is serviceable.

Poor contact at the battery cable connections is often a source of trouble. Make sure battery cables are in good condition and that contacting surfaces are clean and tightly connected. Do not reverse battery leads. Use recommended battery tools when disconnecting leads to avoid mechanical battery damage.

**CAUTION** *This engine uses a 12 volt, negative ground system. Alternator must be connected to battery at all times when engine is running. Do not reverse battery cables.*

# Oil System

## PRESSURE LUBRICATION

Onan engines use an oil pump to lubricate engine parts (Figure 13). If oil pressure is low, the pump should be checked.




FIGURE 13. OIL SYSTEM

## OIL PUMP

The oil pump (Figure 14) is mounted on the front of the crankcase behind the gear cover and is driven by the crankshaft gear.




FIGURE 14. OIL PUMP ASSEMBLY

The inlet pipe and screen assembly is attached directly to the pump body. A discharge passage in the cover of the pump registers with a drilled passage in the crankcase. Parallel passages distribute oil to the front main bearing, rear main bearing and pressure control bypass valve. The oil overflow from the bypass valve furnishes lubrication to the camshaft drive gears.

Circumferential grooves in the main bearings supply oil to the connecting rod bearings through drilled passages from each main journal.

A drilled passage connects the front main bearing oil supply to the front camshaft bearing. The flyball governor is lubricated by a drilled passage in the front camshaft journal.

Normal oil pressure should be 30 psi (200 kPa) or higher when the engine is at operating normal temperature. If pressure drops below 30 psi (200 kPa) at governed speed, inspect the oil system for faulty components.

Check the oil pump thoroughly for worn parts. Oil the pump to prime it before reinstalling. Except for gaskets and suction cup, the component parts of the pump are not available individually. Install a new pump assembly if required.

If new oil pump gaskets are installed, they should be the same thickness as those removed. A gasket kit with various thickness gaskets is available.

## OIL BYPASS VALVE

The bypass valve (located to the right and behind gear cover, (Figure 15), controls oil pressure by allowing excess oil to flow directly back to the crankcase.

The valve is nonadjustable and normally needs no maintenance. To determine if abnormal (high or low) oil pressure is caused by a sticky plunger, inspect as follows:

1. Remove 3/8" - 24 x 1 inch capscrew located behind gear cover and under governor arm.
2. Remove spring and plunger with a magnet tool. Clean plunger and spring with a suitable solvent and reinstall.

To remove the valve, unscrew the recessed plug in the rear bearing plate and lift out the spring and plunger




FIGURE 15. BYPASS VALVE

assembly. Determine proper valve operation by checking the spring and plunger according to the following measurements.

- Plunger Diameter ..... .3105 to .3125  
(7.89 to 7.94)
- Spring  
Free Length ..... 2-5/16 in. (58.74 mm)

### CRANKCASE BREATHER

This engine uses a crankcase breather valve for maintaining crankcase vacuum. If the crankcase becomes pressurized as evidenced by oil leaks at the seals, clean baffle pack and valve in a suitable solvent. See Figure 16.




FIGURE 16. CRANKCASE BREATHER

### CRANKCASE OIL

Change crankcase oil every 25 operating hours and only when engine is warm.

To drain, remove the 1/2-inch pipe plug on the rear corner of the oil base. After oil drains, replace the pipe plug and refill crankcase with 3-1/2 pints (4 pints if changing filter) of a good quality detergent oil. Oil must meet or exceed the API (American Petroleum Institute) designation SE or SE/CC. See Figures 1 and 2. For temperatures above 30°F, use SAE 30 oil; for temperatures below 30°F, use 5W30 or 10W.

### OIL FILTER

Change the crankcase oil filter every 50 hours; change more frequently in extremely dusty conditions. Remove the filter by turning counterclockwise with a filter wrench. Before installing a new filter, coat the gasket on the filter base with a light film of new oil. Install by turning clockwise until a light friction is noted, then turn an additional 1/2 turn.




FIGURE 17. OIL DRAIN LOCATION

# Starting System

## ELECTRIC STARTER

Normally the starter will require little or no service other than possible brush replacement. However, if through accident or misuse, the starter requires service or overhaul, the following information will provide the information necessary to perform this service.

### Starter Disassembly

1. Remove the through-bolts and separate the end cap, the housing and the armature (see Figure 18).
2. Disassemble the drive assembly and the drive end cap by loosening the self-locking nut.




FIGURE 18. STARTER DISASSEMBLY

### Inspection of Parts

**Testing Armature for Grounds:** Touch armature shaft or core and the end of each commutator bar with a pair of ohmmeter leads. If the ohmmeter reading is low, it indicates a grounded armature. Replace grounded armature. See Figure 19.

**Testing Armature for a Short Circuit:** Use a growler for locating shorts in the armature. Place armature in growler and hold a thin steel blade (e.g. hacksaw blade) parallel to the core and just above it while slowly rotating armature in growler. A shorted armature will cause the blade to vibrate and be attracted to the core. If armature is shorted, replace with a new one (Figure 20).

**Inspecting for an Open Circuit in Armature:** The most likely place to check for an open circuit is at the commutator riser bars. Inspect for loose connections on the points where the conductors are joined to the commutator bars.




FIGURE 19. TESTING ARMATURE FOR GROUNDS

**Brush Inspection:** If brushes are worn shorter than 1/4 inch (6.35 mm), replace them. Check to see that brushes move smoothly in the brush holders. See Figure 21.




FIGURE 20. TESTING ARMATURE FOR SHORT CIRCUITS

**Housing Inspection:** Magnets are glued to inside of housing. Magnets must be secure and free of cracks.




FIGURE 21. BRUSH WEAR LIMIT

6. Torque stop nut to a value of 20 to 25 ft-lbs (27 to 34 N•m).
7. Torque thru-bolts to a value of 4.5 to 6 ft-lbs (6 to 8 N•m).

### Checking Gear Lash

Always check starter-to-flywheel gear lash when reinstalling the starter on the engine. Lash should also be checked if the starter binds or slips during cranking or is excessively noisy. Proceed as follows:

1. Before installing the starter, make sure the starter mounting surfaces on the engine base are free of dirt and oil to assure good electrical contact.
2. Install the starter motor and tighten the mounting bolts just enough to hold the starter in place.
3. Remove the spark plugs from the engine to allow free movement of the flywheel.
4. Manually pull the starter pinion gear outward on its shaft so that its teeth mesh fully with those on the flywheel.
5. Measure the amount of free travel (lash) between the pinion gear teeth and the ring gear teeth, as shown in Figure 22. Proper lash is 0.020  $\pm$  0.010 in. (0.51  $\pm$  0.25 mm). Loosen and adjust the starter motor, as necessary, to obtain the correct setting.
6. Torque starter mounting bolts and reinstall the engine spark plugs.

**CAUTION** Failure to torque starter bolts properly may cause starter failure and ring gear damage.

### Starter Assembly

1. Before reassembling the starter, wipe off any dirt from parts with a clean cloth or blow off with filtered, compressed air.

**CAUTION** Do not immerse bearings in cleaning fluid. Use a brush dipped in clean engine oil for dirt removal.

2. Assemble brushes so that the chamfered side is away from the brush springs. Make sure brush wires do not rub against the commutator or end cap.
3. Torque brush screws to a value of 3 to 3-1/2 ft-lbs (4 to 5 N•m).
4. Torque input stud nut to a value of 4 to 5 ft-lbs (5 to 7 N•m).
5. Apply a thin film of grease to the commutator end of the armature shaft and to the portion of the shaft that contacts the bearings. Apply a generous film of silicone base grease (GE Versilube 322-L) to the shaft threads.




FIGURE 22. CHECKING STARTER GEAR LASH

ES-1003

# Engine Disassembly

## DISASSEMBLY/ASSEMBLY

When complete engine disassembly is necessary, first remove all complete assemblies. Individual assemblies such as fuel pump and carburetor can be disassembled and repaired at another time.

### Suggested Disassembly Order

1. Drain crankcase.
2. Disconnect all exhaust lines and electrical lines.
3. Remove engine from its mountings and place on a suitable bench or work stand.
4. Remove all housings, shrouds, blower housings, etc.
5. Remove flywheel, using a puller. Remove flywheel key.
6. Remove the gear cover, being careful to protect the oil seal from keyway damage.
7. Remove the crank gear, Using a gear puller and ring.
8. Remove all accessories such as oil filter, starter, intake manifold, fuel lines, spark plugs, etc.
9. Remove breaker point box.
10. Remove oil base, oil pump, and cylinder heads.
11. Remove valves, springs, lifters, etc.
12. Remove camshaft and gear assembly.
13. Remove connecting rods and pistons.
14. Remove rear bearing plate.
15. Remove crankshaft.
16. Remove front bearing.

Keep all parts in their respective orders. Keep tappet and valve assemblies together. Return rod caps to their respective pistons. Analyze the reasons for parts failure.

### Suggested Assembly Procedure

Engine assembly is normally the reverse of the disassembly procedure, observing proper clearances, and torques. Use a torque wrench to assure proper tightness. Coat internal engine parts with oil as they are assembled. After internal engine parts are assembled, the engine should turn over freely by hand. Use only genuine Onan parts and special tools when reassembling your engine.

1. Install front main bearing in cylinder block.
2. Insert rear main bearing in rear bearing plate.

3. Insert crankshaft and rear bearing plate.
4. Install crank gear.
5. Install piston and connecting rods.
6. Install camshaft and gear assembly; align crank gear mark with cam gear mark.
7. Install valve assemblies.
8. Install oil pump, oil base, and cylinder heads.
9. Install breaker point box.
10. Install all accessories, such as oil filter, starter, fuel lines, and spark plugs.
11. Install gear cover and oil seal.
12. Install flywheel.
13. Set breaker points to obtain proper timing.
14. Check valve clearance.
15. Install all housings and air cleaner.
16. Fill crankcase with oil.

### Operation

Start engine and check oil pressure. Run for approximately 15 minutes to bring engine to operating temperature. Check for oil leaks, fuel leaks, and exhaust leaks. Adjust carburetor and governor for speed and sensitivity.

### Tappet Adjustment

The engine is equipped with adjustable valve tappets. The valve tappet clearance should be checked and adjusted, if necessary, at least every 200 operating hours or when poor engine performance is noticed. Adjust the valve clearance only when engine is at ambient temperature. Proceed as follows:

1. Remove ignition key to prevent accidental starting.
2. Remove all parts necessary to gain access to valve tappets.
3. Remove spark plugs to ease the task of turning the engine over by hand.
4. Use the engine flywheel to turn the engine over slowly by hand until the left hand intake valve opens and closes. Continue turning the flywheel until the TC mark is on the top and lined up with the TC mark on the gear cover. Both valves should be closed. This should place the left hand piston at the top of its compression stroke, the position it must be in to get proper valve adjustment for the left cylinder.

5. Clearances are given in *Specifications section*. For each valve, the gauge should just pass between the valve stem and valve tappet (Figure 24).
6. To correct the valve clearance, turn the adjusting screw as needed to obtain the right clearance. The screw is self locking.
7. To adjust valves on the right hand cylinder, turn engine one complete revolution. Then line up mark on the flywheel and the TC mark on the gear cover. Follow adjustment procedure given for left hand cylinder.
8. Replace all parts removed. Tighten all screws securely. Torque manifold bolts.

## VALVE SYSTEM

Properly seated valves are essential to good engine performance. The aluminum cylinder heads are removable for valve servicing. Do not use a pry bar to loosen the cylinder head: rap sharply on the edge with a soft faced hammer, taking care not to break any cooling fins. A conventional type valve spring lifter may be used when removing the valve spring locks, which are of the split type. Clean all carbon deposits from the cylinder heads, piston tops, valves, guides, etc. If a valve face is burned or warped, or the stem worn, install a new one. Refer to Figure 23.

An optional valve stem seal is used on the intake valve guides of some engines. This seal must be replaced each time the valve is removed.

Worn valve stem guides may be replaced from inside the valve chamber. Valve locks are split, tapered type, of which the smaller diameter must face toward the valve head. Tappets are also replaceable from the valve chamber, after first removing the valve assemblies.

The valve face angle is 44 degrees. The valve seat angle is 45 degrees. This 1-degree interference angle results in a sharp seating surface between the valve and the top of the valve seat. The interference angle method of grinding valves minimizes face deposits and lengthens valve life.

The valves should not be hand lapped, if at all avoidable, because the sharp contact may be destroyed. This is especially important where chrome-cobalt faced valves and seats are used. Valve faces should be finished in a machine to 44 degrees. Valve seats should be ground with a 45-degree stone and the width of the seat band should be 1/32-inch to 3/64-inch (0.79 to 1.2 mm) wide. Grind only enough to assure proper seating.

Remove all grinding compound from engine parts and place each valve in its proper location. Check each valve for a tight seat, using an air pressure testing tool. If such a tool is not available, use machinist blueing or a felt tip pen to mark the valve face and observe if the marks rub off uniformly when the valve is rotated part of a turn against the seat. Lightly oil the valve stems and assemble all parts removed.

The positive type valve rotators prolong valve life and decrease valve repairs. When functioning properly, the valve is rotated a fraction of a turn each time it opens. While at open position, the valve must rotate freely. If rotators are faulty, install new rotators.



NOTE USE A STANDARD AUTOMOTIVE TYPE WRENCH TO ADJUST THE TAPPETS




FIGURE 23. VALVE ASSEMBLY

VT-1005




FIGURE 24. VALVE CLEARANCE

## FLYWHEEL

Removing the flywheel is a relatively simple process, but the following procedure must be followed to avoid damage to the gear case and possible injury to the operator.

1. Turn the flywheel mounting screw outward about two turns.

**CAUTION** Do not remove the screw completely since it acts as a restrainer when the flywheel snaps loose. If the flywheel is not held by the screw, the spring action in the wheel will cause it to fly off with great force which can cause injury to the operator.

2. Install a puller bar on the flywheel as shown in Figure 25.




FIGURE 25. BLOWER WHEEL PULLER

3. Turn the puller bar bolts in, alternately, until the wheel snaps loose on the shaft.

**CAUTION** Do not use a screwdriver or similar tool or pry behind the flywheel against the gear case. The gear case cover is die-cast material and will break if undue pressure is applied in this manner.

4. Unscrew the puller from the flywheel, remove the flywheel mounting screw and washer and pull the flywheel off the shaft. Take care not to drop the wheel. A bent or broken fin will destroy the balance. Always use a steel key for mounting the flywheel.

## GEAR COVER

After removing the mounting screws, tap the gear cover gently with a soft faced hammer to loosen it (see Figure 26).

When installing the gear cover, make sure that the pin in the gear cover engages the nylon lined (smooth) hole in the governor cup. Turn the governor cup so that the nylon lined hole is at the three o'clock position. Use a small amount of grease to assist in holding governor cup in position. The smooth side of the governor yoke must ride against the governor cup. Turn the governor arm and shaft clockwise as far as possible and hold in this position until the gear cover is installed flush against the crankcase. Be careful not to damage the gear cover oil seal.








FIGURE 26. GEAR COVER ASSEMBLY



5 BALL GOVERNOR



6 BALL GOVERNOR



8 BALL GOVERNOR

FLYBALL LOCATIONS

CS-1238

FIGURE 27. GOVERNOR CUP DETAILS

## GOVERNOR CUP

With the gear cover removed, the governor cup can be taken off after removing the snap ring from the camshaft center pin. Catch the flyballs while sliding the cup off (Figure 27).

Replace with a new part any flyball which is grooved or has a flat spot; the ball spacer if its arms are worn or otherwise damaged; and the governor cup if the race surface is grooved or rough. The governor cup must be a free-spinning fit on the camshaft center pin, but without any excessive play.

When installing the governor cup, tilt the engine so the gear is up, put the flyballs in place (Figure 27) and install the cup and snap ring on the center pin.

The camshaft center pin extends out 3/4 inch (19 mm) from the end of the camshaft. This distance provides an in-and-out travel distance of 7/32 inch (5.6 mm) for the governor cup, as illustrated. Hold the cup against the flyballs when measuring. The camshaft center pin cannot be pulled outward or removed without damage. If the center pin extends out too far, the cup will not hold the flyballs properly. If the distance is less than 7/32" (5.6 mm), (the engine will race, especially at no load) remove the center pin and press in a new pin.

## TIMING GEARS

If replacement of either the crankshaft gear or the camshaft gear becomes necessary, always install both gears new.

The camshaft and gear must be replaced as an assembly. Before removing the camshaft and gear assembly, remove the cylinder head and valve assemblies. Then remove the operating plunger for the breaker points and tappets.

To remove the crankshaft gear, first remove the snap ring and retainer washer, then attach the gear pulling ring using two No. 10-32 screws (Figure 28). Tighten the screws alternately until both are tight. Attach a gear puller to the puller ring and proceed to remove the gear.

Each timing gear is stamped with "O" near the edge. The gear teeth must mesh so that these marks exactly coincide when the gears are installed in the engine. When installing the camshaft gear and shaft assembly, be sure that the thrust washer is properly in place behind the camshaft gear. Then install the crankshaft retaining washer and lock ring.





FIGURE 28. TIMING GEAR REMOVAL AND INSTALLATION

### PISTONS AND CONNECTING RODS

Observe the following procedure when removing pistons and connecting rods from the engine.

1. Drain oil.
2. Remove the cylinder head and oil base pan from the engine.
3. Remove carbon from top of cylinder bore and check for a ridge. Remove ridge (Figure 29) with a ridge reamer before attempting piston removal.

**CAUTION** *Using a ridge reamer to remove carbon can cause damage to cylinder bore.*




FIGURE 29. REMOVING RIDGE FROM CYLINDER

**CAUTION** *Forcing the piston from the cylinder before reaming may cause damage to the piston lands and break rings.*

4. Turn the crankshaft until the piston is at the bottom of its stroke, and remove the connecting rod nuts. Lift the rod bearing cap from the rod, and

push the rod and piston assembly out through the top of the cylinder, using a hammer handle. Avoid scratching the crankpin and cylinder wall when removing the piston and rod.

Mark each piston and rod assembly so they can be returned to their respective cylinders after overhaul. Keep connecting rod bearing caps with their respective rods.

5. Remove the piston rings from the piston with a piston ring spreader as shown in Figure 30. Remove the piston pin retainer and push the piston pin out.




FIGURE 30. REMOVING PISTON RINGS

Remove dirt and deposits from the piston surfaces with an approved cleaning solvent. Clean the piston ring grooves with a groove cleaner or the end of a piston ring filed to a sharp point (Figure 31). Care must be taken not to remove metal from the groove sides or bottom.

**CAUTION** Do not use a caustic cleaning solvent or wire brush for cleaning pistons. These materials will cause piston damage.





FIGURE 31. PISTON GROOVE CLEANING

When cleaning the connecting rods in solvent, include the rod bore. Blow out all passages with compressed air.

Engines that have been fitted with 0.005 inch (0.13 mm) oversize pistons at the factory are identified by the letter E after the serial number. Number is stamped on the cylinder block and on the unit nameplate.

### Inspection

The following text contains inspection procedures concerning pistons and connecting rods.

#### Piston Inspection:

1. Inspect the pistons for fractures at the ring lands, skirts, and pin bosses. Check for wear at the ring lands, using a new ring and feeler gauge as shown in Figure 32. Replace the piston when the side clearance of the top compression ring reaches 0.006 inch.




FIGURE 32. CHECKING RING SIDE CLEARANCE

2. Replace pistons showing signs of scuffing, scoring, worn ring lands, fractures, or damage from pre-ignition. Excessive piston wear near the edge of the top ring land indicates pre-ignition.
3. Proper piston tolerances must be maintained for satisfactory operation.
4. Measure the piston to cylinder clearance, as shown in Figure 33, to be sure the total clearance follows specifications.




FIGURE 33. MEASURING PISTON CLEARANCE

#### Connecting Rod Inspection:

1. Replace connecting rod bolts and nuts with damaged threads. Replace connecting rods with deep nicks, signs of fractures, scored bores or bores out of round more than 0.002 inch.
2. Use a new piston pin to check connecting rod for wear. A push-fit clearance is required and varies from engine to engine. If a new piston pin falls through a dry rod pin bore as a result of its own weight, replace the rod.

### Piston Rings:

1. Install the piston ring in the cylinder bore. Invert the piston and push the ring to the end of ring travel, about halfway into the bore. This trues the ring end gap. Check the gap with a feeler gauge as shown in Figure 34.
2. The practice of filing ring ends to increase the end gap is not recommended. If the ring end gap does not meet specifications, check for the correctness of ring and bore sizes. A cylinder bore that is 0.001 inch (0.03 mm) under size will reduce the end gap 0.003 inch (0.08 mm).





FIGURE 34. POSITIONING OF PISTON RING AND MEASURING OF END GAP

## CYLINDER BLOCK

The cylinder block is the main support for all other basic engine parts. Crankshaft and camshaft are supported by the block, assuring alignment of the crankshaft and cylinder bores.

## Cleaning

After removing pistons, crankshaft, cylinder heads, etc., inspect block for cracks and extreme wear. If block is still serviceable, prepare it for cleaning as follows:

1. Scrape all old gasket material from block. Remove oil by-pass to allow cleaning solution to contact inside of oil passages.
2. Remove grease and scale from cylinder block by agitating in a bath of commercial cleaning solution or hot soapy washing solution.
3. Rinse block in clean hot water to remove cleaning solution.

## Inspection

When rebuilding the engine, thoroughly inspect block for any condition that would make it unfit for further use. This inspection must be made after all parts have been removed and block has been thoroughly cleaned and dried.

1. Make a thorough check for cracks. Minute cracks may be detected by coating the suspected area with a mixture of 25 percent kerosene and 75 percent light motor oil. Wipe the part dry and immediately apply a coating of zinc oxide (white lead) dissolved in wood alcohol. If cracks are present, the white coating will become discolored at the defective area. Always replace a cracked cylinder block.
2. Inspect all machined surfaces and threaded holes. Carefully remove any nicks or burrs from machined surfaces. Clean out tapped holes and clean up any damaged threads.
3. Check top of block for flatness with a straight edge and a feeler gauge.

**Cylinder Bore Inspection:** Inspect cylinder bores for scuffing, scratches, wear, and scoring. If cylinder bores are scuffed, scratched, scored, or worn, they must be rebored and honed for the next oversize piston.

When the appearance of cylinder bores is good and there are no scuff marks, check cylinder bore for wear or out of roundness as follows:

1. Check cylinder bore for taper, out of round, and wear with a cylinder bore gauge, telescope gauge or inside micrometer. These measurements should be taken at four places, top and bottom of piston ring travel, parallel and perpendicular to axis of crankshaft.
2. Record measurements taken at top and bottom of piston travel as follows (see Figure 35):

A. Measure and record as "A" the cylinder bore diameter (parallel to crankshaft) near the top of cylinder bore where greatest amount of wear occurs.

B. Also measure and record as "B" cylinder bore diameter (parallel to crankshaft) at the bottom of piston travel.


C. Measure and record as "C" cylinder bore diameter (perpendicular to crankshaft) near the top of cylinder bore where greatest amount of wear occurs.

D. Also measure and record as "D" cylinder bore diameter (perpendicular to crankshaft) at the bottom of piston travel.

E. Reading "A" subtracted from reading "B" and reading "C" subtracted from reading "D" indicates cylinder taper.

If cylinder taper exceeds 0.003 inch (0.08 mm), rebores and hone cylinder to the next oversize.

F. Reading "A" compared to reading "C" and reading "B" compared to reading "D" indicate whether or not cylinder is out of round. If out of round exceeds .003 inch (0.08 mm), the cylinders must be rebored and honed to the next oversize. A reboring machine is used when going to oversize pistons. The following repair data covers honing to oversize by use of a hone.



C 1090




FIGURE 35. METHODS OF MEASURING THE DIAMETER OF A CYLINDER BORE

**CAUTION** *If boring bar is operated incorrectly, it will produce a rough cylinder surface that may not clean up even when honed. Boring should be done only by qualified service personnel who are careful in their work.*

After boring to the correct oversize cylinder bore dimension piston and ring clearance should be appropriate. There is no need to adjust or "fit" pistons and rings.

When reboring cylinders, take the following precautions:

1. Make sure cutting tool is properly ground before using it.
2. Be sure top of engine block is smooth and deposit free.

## Reboring the Cylinder

Rebore and hone engine whenever cylinder bore is worn, damaged, out of round, or if cylinder taper exceeds specifications. A worn cylinder bore should be resized to the smallest standard oversize diameter at which it will clean up. The final finish and bore diameters should then be obtained by honing.

3. Clean base of boring bar before bar is set up. Deposits under boring bar will cause it to tilt, and the cylinder will be distorted after boring.
4. Make an initial rough cut, followed by a finish cut. Then hone cylinder bore to the specified oversize.

### Honing Cylinders (Using Precision Hones)

Refer to hone manufacturer's recommended grit size to produce specified surface finish of 20 to 40 RMS. Too rough of a finish will wear out the rings and too smooth of a finish can retard piston ring seating.


1. Position block solidly for either vertical or horizontal honing. Use either a drill press or heavy-duty drill which operates at approximately 250 to 450 rpm.
2. Follow hone manufacturer's instructions for the use of oil or lubricant on stones. Do not use lubricants with a dry hone.
3. Insert hone in bore and adjust stones to fit snugly to the narrowest section. When adjusted correctly, the hone should not shake or chatter in cylinder bore, but will drag freely up and down when hone is not running.
4. Connect drill to hone and start drill. Feel out bore for high spots, which cause an increased drag on stones. Move hone up and down in bore with short overlapping strokes about 40 times per minute. Usually bottom of cylinder must be worked out first because it is smaller. As cylinder takes a uniform diameter, move hone up and down all the way through cylinder bore.
5. Check diameter of the cylinder regularly during honing. A dial bore gauge is the easiest method, but a telescoping gauge can be used. Check size at six places in bore; measure twice at top, middle and bottom at 90-degree angles.
6. Crosshatch formed by the stones should form an included angle of 23 degrees. This can be achieved by moving the rotating hone (250 to 450 rpm) up and down in cylinder bore about 40 times per minute.
7. Clean cylinder bores thoroughly with soap, water, and clean rags. A clean white rag should not become soiled on wall after cleaning is complete. Do not use a solvent or gasoline, since they wash oil from the walls but leave metal particles.
8. Dry crankcase and coat it with oil.

### Deglazing Cylinder Bores


Deglaze the cylinder bores if there are no scuff marks and no wear or out of round beyond specifications before installing new rings. Deglazing gives a fine finish but does not enlarge cylinder diameter, so the original pistons with new rings may still be used.

The reason for deglazing a cylinder is to provide cavities to hold oil during piston ring break-in.

1. Wipe cylinder bores with a clean cloth which has been dipped in clean, light engine oil.
2. Use a brush type deglazing tool with coated bristle tips to produce a crosshatch pattern in the cylinder bore.
3. The deglazing tool should be driven by a slow speed drill. Move deglazing tool up and down in cylinder (10 to 12 complete strokes) rapidly enough to obtain a crosshatch pattern as shown in Figure 65.



PRODUCE CROSS HATCH SCRATCHES FOR FAST RING SEATING



AVOID THIS FINISH

C-1091

FIGURE 36. CROSS HATCHING

**CAUTION** Never use gasoline or commercial cleaners to clean cylinder bores after deglazing or honing. These solvents will not remove abrasives from the walls. Abrasives not removed from engine will rapidly wear rings, cylinder walls, and bearing surfaces of all lubricated parts.

4. Clean cylinder bore thoroughly with soap, water, and clean rags. Continue cleaning until a clean white rag shows no discoloring when wiped through cylinder bore.

## CRANKSHAFT

Inspect the bearing journals. If they are scored and cannot be smoothed out by dressing down, the bearing journals should be refinished to use nearest available undersize bearings or a new crankshaft should be installed. If a worn main bearing journal cannot be fitted with an available precision type undersize bearing, then refinish it to the next undersize. If a worn rod journal cannot be fitted by installing new bearing inserts (forged rod), then refinish it to take the next corresponding undersize bearing insert available.

Whenever making major repairs on the engine, always inspect the drilled passages of the crankshaft. Clean them to remove any foreign material and to assure proper lubrication of the connecting rods.

**Shot Peening:** On older model engines, shot peening is required to prevent failures. When the shaft is machined, follow the data to shotpeen each crankpin fillet.

1. Almen gauge reading: 0.012A
2. Mask off connecting rod bearing areas.
3. Peen with 0.019 inch (0.49 mm) diameter cast steel shot.
4. Peen for 30 seconds on each crankpin fillet.

Undersize bearings and connecting rods are available to rework the shaft to 0.010, 0.020, and 0.030 inch undersize.

## BEARINGS

Removal of the camshaft or crankshaft bearings requires complete disassembly of the engine. Use a press or a suitable drive plug to remove the bearings. Support the casting to avoid distortion and to avoid damaging the bearing bore during removal and installation. Use oil on the bearings to reduce friction when installing, and lubricate again with oil after installing (Figure 37). Use combination bearing driver 420-0324 to install the camshaft bearings.

PRECISION TYPE -DO NOT LINE REAM OR BORE.




FIGURE 37. CAMSHAFT BEARING

Replacement camshaft bearings are precision type which do not require line reaming or line boring after installation. Coat the bearing with lubricating oil to reduce friction. Place the bearing with the lubricating hole (front only) in proper position. Be sure to start the bearing straight. Press in the front bearing flush with the outside end of the bearing bore. Front cam bearing oil hole must line up with oiling hole in cylinder block. Press in the rear bearing until past the ignition plunger hole.

New crankshaft main bearings are precision type which *do not* require line reaming or line boring after installation. They are available in standard size, 0.002, 0.010, 0.020, or 0.030 inch undersize.

Before putting in the main bearings, expand the bearing bore by placing the casting in hot water or in an oven heated to 200°F (94°C). If practical, cool the precision bearing to shrink it.

**CAUTION** If a torch is used, apply only a little heat. Distortion will result from too much local heat.

To ease assembly, cool the precision bearing to shrink it. Align the oil hole(s) in the bearing with the oil hole(s) in the bearing bore (Figures 38 and 39). The oil passage must be at least half open. The cold precision bearing should require only light taps with a driving tool to position it. In the rear bearing plate, install the bearing flush to 1/64 inch (0.40 mm) below the end of the bore. If head of lock pin is damaged, use side cutters or Easy Out tool to remove and install new pin. Oil grooves in thrust washers must face the crankshaft, and washers must be flat (not bent). The two notches on each washer must fit over the two lock pins to prevent riding on the crankshaft.




FIGURE 38. BEARINGS FOR REAR BEARING PLATE

Engines shipped from the factory have separate thrust washers and main bearings for both front and rear of engine. Front bearing replacement part is a one piece bearing (with attached thrust washer) as shown in Figure 39. Do not add an additional thrust washer to this front bearing.

NOTE: Do not add additional thrust washer when replacing front bearing.




FIGURE 39. FRONT BEARING INSTALLATION

Before installing the front bearing, use the Locktite Bearing Mount furnished in the bearing kit. Use the towelette in the package to clean the outside of the bearing and the bearing bore in the block.

**CAUTION** Breathing vapor from towelette and prolonged contact with skin can be harmful. Be sure area is well ventilated.

After allowing three to four minutes for drying, apply the Locktite Bearing Mount from the small tube to the mating surfaces of the bearing and bearing bore. Install the bearing flush with the block, using the combination driver just used for the rear bearing. Wipe off any excess Locktite around the bearing. Allow at least one hour for hardening at room temperature.

Lubricate the front main bearing lightly with oil and insert the crankshaft. With the rear bearing plate gasket in place and the rear plate bearing lubricated, slide the thrust washer (grooves toward crankshaft) and plate over the end of the crankshaft. Line up notches of thrust washer with lock pins before tightening end plate or lock pins will be damaged.

A light film of oil on the thrust washer may hold it in place while installing the crankshaft.

### CRANKSHAFT ENDPLAY

After the rear bearing end plate has been tightened, using the torque recommended in *Assembly Torques and Special Tools*, check the crankshaft endplay as shown in Figure 40. If there is too much endplay (see *Dimensions and Clearances* for minimum and maximum endplay), remove the rear bearing end plate and add a shim (Figure 38) between the thrust washer and plate. Reinstall the end plate, making sure the thrust washer and shim notches line up with the lock pins. Torque and recheck endplay of the crankshaft.




FIGURE 40. CRANKSHAFT ENDPLAY




FIGURE 41. GEAR COVER AND REAR BEARING PLATE OIL SEALS

### OIL SEALS

The bearing plate must be removed to replace its oil seal. Drive the oil seal out from the inside, using bearing plate driver and gear cover driver.

Before installing the seals, fill the space between seals with a fibrous grease or stiff cup grease. This will improve sealing. See Figure 41.

When installing the gear cover oil seal, press the seal inward until it is 1-1/32 inch (26.2 mm) from the mounting face of the cover. Install new style, thin open face seal, 1-7/64 inches (28.18 mm) from mounting face of cover.

When installing the bearing plate oil seal, press the seal into the bearing plate bore to bottom against the shoulder in the plate bore. Use a seal expander, or place a piece of shim stock around the end of the crankshaft, when replacing the bearing plate to avoid damaging the seal. Remove the shim stock as soon as the plate is in place.

Engines equipped with some types of reduction gear assemblies do not use the rear oil seal. The reduction gear assembly is oiled directly from the engine crankcase. Refer to the instructions screened on the case of the reduction gear assembly.

### OIL PUMP

To remove the oil pump, it is necessary to detach the intake cup assembly as shown in Figure 42.

Check the oil pump thoroughly for worn parts. Oil the pump to prime it before installing. Except for gaskets, the component parts of the pump are not available individually. The suction cup is available separately. Install a new pump assembly, if required.




FIGURE 42. OIL PUMP ASSEMBLY

### PISTON ASSEMBLY

1. Lubricate all parts with engine oil.
2. Position piston on its respective rod and install the pin.
3. Install the rings on the pistons starting with the oil control ring (Figure 43). Use a piston ring spreader to prevent twisting or excessive expansion of the ring. Compression rings have a dot or the word "top" on one side of the ring to indicate which side faces the top of the piston. Unmarked piston rings can be installed either way. The oil control ring has an expander; install the expander first and then close until the expander ends butt. The joint should be 180 degrees from the gap of that ring.




FIGURE 43. PISTON RINGS

### INSTALLATION OF PISTON IN CYLINDER


1. Turn the crankshaft to position the number one rod bearing journal at the bottom of its stroke.
2. Lubricate the number one piston assembly and the inside of the cylinder. Compress the rings with a ring compressor as shown in Figure 44.
3. Position the piston and rod assembly in the cylinder block. Oil hole in connecting rod must face camshaft.

**Rod bolts are off-set toward outside of block.**

4. Tap the piston down into the bore with the handle end of a hammer until the connecting rod is seated on the journal (Figure 44). Install the bearing cap on the rod. Install and tighten the bolts evenly, in steps, to the specified torques.

The bearing cap must be tapped to align it properly with the rest of the connecting rod. Clearance varies on the journal if this is not done.

5. Install the remaining piston and rod in the same manner. Crank the engine over by hand to see that all bearings are free.
6. Install oil pump pick up tube and cap.
7. Install the oil base with a new gasket.
8. Install the cylinder heads. See *Cylinder Head* section for torques and torquing procedure.
9. Replace oil and break in engine.



CT-1077




FIGURE 44. INSTALLING PISTON AND CONNECTING ROD

## CYLINDER HEAD GASKET REPLACEMENT

Remove the cylinder heads for lead cleaning and gasket change at least every 200 hours, or when poor engine performance is noticed. For engines running on unleaded fuel this interval may be extended to 400 hours.

1. Use a 1/2 inch (13 mm) socket wrench to remove cylinder head bolts. Lift heads off.

**CAUTION** Do not torque or remove heads when they are hot. Warpage may occur. The gasket surface must be below 100° F before removal. At temperatures above 100° F, the gasket will become gummy and difficult to remove from the surface of the block and cylinder head.

2. After removing heads, clean out all carbon deposits. Be careful not to damage the outer sealing edges where gaskets fit. The heads are made of aluminum and can be damaged by careless handling.
3. Use new head gaskets, and clean both the heads and the cylinder block thoroughly where the head gaskets rest.
4. Place a head gasket on the cylinder head, and align the stud holes in the gasket with the stud holes in the cylinder head. While holding the gasket against the cylinder head, carefully install the cylinder head on the engine. Do not attempt to slide the gasket over the studs without the cylinder head behind it or the gasket may tear.
5. Some engines have two compression washers and one hardened washer on the long cylinder head studs (top 6 studs on each side) as shown in Figure 45. When these washers are used, they must be installed as shown. When properly installed, only the outside edges of the compression washers will be in contact with each other. Install a flat washer and nut on each of the four bottom studs.
6. Follow the head torque sequence shown in Figure 46.

### A. Asbestos head gasket torque procedure:

Tighten all nuts to 5 ft-lb (7 Nm), then 10 ft-lb (14 Nm), etc. until all nuts are torqued to 18 to 20 ft-lb (24-27 Nm). Recheck all head nuts for correct torque.

**WARNING** Asbestos gaskets contain fibers that when airborne may be harmful to your health. Use a respirator when handling and installing gaskets.

### B. Graphoil head gasket torque procedure:

Start out tightening all nuts to 5 ft-lb (7 Nm), then 10 ft-lb (14 Nm), etc., until the correct torque is reached. The top six nuts should be tightened to 12 ft-lb (16 Nm) and the bottom four nuts should be tightened to 15 ft-lb (20 Nm).

After the head nuts have been tightened once, it will be necessary to tighten each head nut to the specified torque a second time. Follow the same sequence shown in Figure 46. Failure to retorque could result in a blown head gasket.




FIGURE 45. CYLINDER HEAD WITH COMPRESSION WASHERS

**CAUTION** Too much torque will flatten the compression washers and could result in engine damage.

7. Recheck torque before engine has run a total of 50 hours.




FIGURE 46. HEAD BOLT TIGHTENING SEQUENCE

## CYLINDER HEAD STUD TEST AND REPLACEMENT PROCEDURE

This cylinder head stud replacement procedure should be used whenever replacing any of the top six studs on the block. The use of a Helicoil is not a recommended repair procedure. If a Helicoil has been used, the cylinder block must be replaced. Graphoil head and intake manifold gaskets should also be used when replacing cylinder head studs.


### Parts Required

Part No.	Description
520-0912	Step stud
110-2987	Head gasket
154-2219	Intake manifold gasket
420-0398	Drilling fixture (Reusable tool)

1. Disconnect the spark plug wires and remove the spark plugs and cylinder head air shrouds from each cylinder.
2. Remove the nuts and compression washers (do not remove the flatwashers) from the top six studs on each cylinder head (see Figure 47). Each stud will have two compression washers and one flatwasher arranged in the sequence shown in Figure 48.

**Do not remove the nuts from the bottom four studs before the test procedure is completed.**

USE STUDS SHOWN ABOVE LINE FOR SECTION 1 STUD TEST



NUMBERS INDICATE CORRECT TIGHTENING SEQUENCE FOR CYLINDER HEAD NUTS

FIGURE 47. CYLINDER HEADS




FIGURE 48. CYLINDER HEAD STUDS

3. Replace the nuts and then test the top six cylinder head studs by tightening (use an accurate torque wrench) each nut to 30 ft-lb (40 Nm) of torque. Make a note of any studs that cannot be tightened to 30 ft-lb of torque.
4. Remove the cylinder-head nuts, flatwashers, cylinder head, and head gasket. Discard the head gasket and remove any studs that could not be torqued to 30 ft-lb (40 Nm) without thread pull out.
5. Examine the gasket surfaces of the block and cylinder head for distortion or irregularities that could cause leakage. Check the head and block for warpage by laying a straight edge over the length of the gasket surface. If a 0.005 inch feeler gauge fits between the straight edge and gasket surface, the part must be replaced or milled flat. A maximum of 0.010 inch may be machined from the cylinder block or head.

## CYLINDER HEAD STUD TEST AND REPLACEMENT PROCEDURE

This cylinder head stud replacement procedure should be used whenever replacing any of the top six studs on the block. The use of a Helicoll is not a recommended repair procedure. If a Helicoll has been used, the cylinder block must be replaced. Gra-phil head and intake manifold gaskets should also be used when replacing cylinder head studs.

### Parts Required

Part No.	Description
520-0912	Step stud
110-2987	Head gasket
154-2219	Intake manifold gasket
420-0398	Drilling fixture (Reusable tool)

1. Disconnect the spark plug wires and remove the spark plugs and cylinder head air shrouds from each cylinder.

2. Remove the nuts and compression washers (do not remove the flatwashers) from the top six studs on each cylinder head (see Figure 47). Each stud will have two compression washers and one flatwasher arranged in the sequence shown in Figure 48.

Do not remove the nuts from the bottom four studs before the test procedure is completed.

USE STUDS SHOWN ABOVE LINE FOR SECTION 1 STUD TEST




FIGURE 47. CYLINDER HEADS  
NUMBERS INDICATE CORRECT  
TIGHTENING SEQUENCE FOR  
CYLINDER HEAD NUTS




FIGURE 48. CYLINDER HEAD STUDS

3. Replace the nuts and then test the top six cylinder head studs by tightening (use an accurate torque wrench) each nut to 30 ft-lb (40 Nm) of torque. Make a note of any studs that cannot be tightened to 30 ft-lb of torque.

4. Remove the cylinder-head nuts, flatwashers, cylinder head, and head gasket. Discard the head gasket and remove any studs that could not be torqued to 30 ft-lb (40 Nm) without thread pull out.

5. Examine the gasket surfaces of the block and cylinder head for distortion or irregularities that could cause leakage. Check the head and block for warpage by laying a straight edge over the length of the gasket surface. If a 0.005 inch feeler gauge fits between the straight edge and gasket surface, the part must be replaced or milled flat. A maximum of 0.010 inch may be machined from the cylinder block or head.


## INTAKE MANIFOLD GASKET REPLACEMENT

1. Remove the governor control rod from the governor arm and the breather tube from the air cleaner.
2. Remove all dirt from the area around the intake manifold and cylinder head interface. Remove the four bolts holding down the intake manifold assembly, and move the manifold so that it is possible to work on the gasket area.
3. Remove the intake manifold gasket. On some models, the intake manifold gasket is tied to the exhaust manifold gasket. In these cases, use a cutting tool (chisel) to separate the intake manifold section of the gasket. Follow the outline of the exhaust manifold as closely as possible when cutting.
4. Install the new intake manifold gasket, making sure it is properly positioned. Make certain the outline of the gasket follows outline of port. Installing the gasket upside down will allow air leakage. This will cause lean operation and allow entry of dirt which will eventually lead to engine destruction.
5. Reinstall the intake manifold tightening the four hold down bolts to 20 to 23 ft-lb (27-31 Nm) of torque.
6. Reattach the governor control rod and air cleaner breather tube.

**CAUTION**

*Do not reuse any gaskets which have been damaged by tearing, erosion, or galling.*

# WIRING DIAGRAM FOR FLYWHEEL ALTERNATOR (PHELON 15 AMP)





Onan Corporation  
1400 73rd Avenue N.E.  
Minneapolis, Minnesota 55432

Telephone: (612) 574-5000  
Telex: 275477  
Cable: ONAN