



# 6-Pin Wire Harness Assembly Installation Guide


Connect leads as shown per your service part number.  
An adapter wire, illustrated, may be required when connecting  
the alternator system.



## 698330 – Models 400000/440000 OHV (See also 696576)




## 696576 – Models 400000/440000 OHV (Models equipped with Engine Minder™)




(over)

## 698329 – Models 280000 & 310000 OHV and L-Head



## 698332 – Models 290000, 300000, 350000, & 380000 OHV Vanguard™ Series



## 698331 – Models 420000 & 460000

